How to set the DL4422 modem as bridge mode

The default setting has been set to Bridge mode for WAN Interface. The following steps will help you to check.

1. Setup > WAN, this page shows currently established WAN interfaces.

2. In this page, please follow steps if you just want to modify existed interface.
   (a) Select the interface you want to change or modify
   (b) Change any settings you want
   (c) Click “Modify” button to save

3. If you just want to create new interface, please do not click existed interface. Only choose your settings and click “Add” button to save.

4. Next will show you about details.

(a) Channel Type : ATM for ADSL, PTM for VDSL

(b) Channel Mode : Bridge / IPoE(DHCP or Static IP) / PPPoE / PPPoA / 1483 Routed

(c) You just need to select these two items for bridge mode.