

QUICK START GUIDE

MODEM: TECHNICOLOR TC4400

1

CHECK THE BOX CONTENTS

Look in the box and make sure you have the following:



TECHNICOLOR
TC4400



ETHERNET CABLE
(RJ-45)



TECHNICOLOR TC4400
POWER ADAPTER



COAXIAL CABLE
(OPTIONAL)

To download the full manual of **Technicolor TC4400**, please visit:
www.carrytel.ca/download/technicolortc4400.pdf

If you need help to set up the equipment, please contact us at
647-560-4448 and go to Line 2 for Technical Support

2

CONNECT THE MODEM TO THE CABLE OUTLET

Connect the coaxial cable from the modem to the cable outlet as indicated below.



3

CONNECT THE POWER ADAPTER TO THE MODEM

Connect the power adapter DIRECTLY from the wall outlet to the modem as indicated below.

REMINDER:
Connect your own router
or computer here

